

FLOCCING A POOL

For "green" pools:

- Brush up walls and floor.
- Get ALL leaves out.
- Add water to pool until it is at the top of the skimmer.
- Add 6 lbs of shock and wait 30 min.
- Adjust pH to 8.4 by adding the recommended amount of pH up.
- Run filter for 2 hours.
- Shut pump off and let water settle.
- Then dilute in a bucket of water the recommended number of bottles of Floc individually and spread over entire pool.
- Leave pump off and let debris settle for 12 to 48 hours.
- Vacuum on "waste" or "bypass" (goes straight through the pool not through the pump).
- Add more water, then let it settle.
- Vacuum waste again as needed. Sometimes it takes 3 times to vacuum on "waste" before all the debris is gone.
- Bring in water sample for testing.